

PD-35x Series

PD-350

PD-351

PD-352

Digital Multimeter




0 MI2107



SAFETY NOTES

Read the user's manual before using the equipment, mainly "**SAFETY RULES**" paragraph.

The symbol  on the equipment means "**SEE USER'S MANUAL**". In this manual may also appear as a Caution or Warning symbol.

WARNING AND CAUTION statements may appear in this manual to avoid injury hazard or damage to this product or other property.















USER'S MANUAL VERSION

Version	Date
2.0	September 2018

SAFETY RULES

- * **The safety could not be assured if the instructions for use are not closely followed.**
- * This equipment can be used in **Overvoltage Category III** installations and **Pollution Degree 2 environments**.
- * When using some of the following accessories use only the **specified** ones to ensure safety:
 - One pair test leads
- * Review the state of the test ends before its use.
- * Observe all **specified ratings** of measurement.
- * Remember that voltages higher than **60 V DC** or **33 V AC rms** are dangerous.
- * Use this instrument under the **specified environmental conditions**.
- * The user is only authorised to:
 - Battery replacement
 - Fuses
- * On the Maintenance section proper instructions are given.
- * Any other change on the equipment should be carried out by qualified personnel.
- * Follow the **cleaning conditions** described in the Maintenance paragraph.
- * Observe all **specified ratings** for measurement.

* Symbols related with safety:

	DIRECT CURRENT		ON (Supply)
	ALTERNATING CURRENT		OFF (Supply)
	DIRECT AND ALTERNATING		DOUBLE INSULATION (Class II protection)
	GROUND TERMINAL		CAUTION (Risk of electric shock)
	PROTECTIVE CONDUCTOR		CAUTION REFER TO MANUAL
	FRAME TERMINAL		FUSE
	EQUIPOTENTIALITY		EQUIPMENT OR COMPONENT TO BE RECYCLED

Descriptive Examples of Over-Voltage Categories

- Cat I** Low voltage installations isolated from the mains.
- Cat II** Portable domestic installations.
- Cat III** Fixed domestic installations.
- Cat IV** Industrial installations.

TABLE OF CONTENTS

1	Introduction	1
1.1	Features.....	1
2	Setting Up.....	2
2.1	General Inspection.....	2
2.2	Install the Batteries	4
2.3	Adjusting the Tilt Stand	5
2.4	Power On	5
2.5	Sleep Mode.....	5
2.6	Backlight Control	6
2.7	Selecting the Range	6
2.8	Description	7
3	Measurements	13
3.1	Measuring AC or DC Voltage.....	13
3.2	Measuring Resistance	14
3.3	Testing Diodes	14
3.4	Testing for Continuity	15
3.5	Measuring Capacitance	16
3.6	Measuring Frequency	17
3.7	Measuring Transistor	17
3.8	Measuring Temperature.....	18
3.9	Measuring DC or AC Current.....	18
4	Tools	20
4.1	Data Hold Mode.....	20
4.2	Capturing Max. and Min. Values.....	20
4.3	Making Relative Measurements.....	21
4.4	Buzzer Feature	21
5	Bluetooth Function (PD-351 and PD-352)	23
5.1	System Requirements of Mobile Devices	23
5.2	Install the application software	23
5.3	How to Connect.....	24
5.4	User Interface	27
6	Operations	29

7	Technical Specifications.....	33
8	Maintenance.....	37
8.1	Cleaning the multimeter	37
8.2	Replacing the battery	37
8.3	Fuse replacement	38

Digital Multimeter

PD-35x Series

1 Introduction

1.1 Features

- Data transferring via Bluetooth, interacting with mobile device to read measurements, analyze via special chart mode, remote control, voice-out feature; voice warning supported, which enhances measurement safety (only in PD-351 and PD-352).
- $3\frac{5}{6}$ digit reading, achieving higher measurement accuracy than $3\frac{1}{2}$ or $3\frac{3}{4}$ digit counterparts.
- Larger display, easier data-reading; analog bar graph is displayed synchronously.
- Connect simultaneously with two multimeters supported via mobile APP.
- Temperature measuring function.
- Backlit-powered screen, more suitable for dark measurement environment.
- Smart power-off function, extending battery life.
- Thin-tipped test lead (optional) to measure the pins of small package device.
- True RMS value available (only in PD-352 and PD-350).

2 Setting Up

2.1 **General Inspection**

After you get a new multimeter, make a check on the instrument according to the following steps:

1. **Check whether there is any damage caused by Transportation.**

If it is found that the packaging carton or the foamed plastic protection cushion has suffered serious damage, do not throw it away first till the complete device and its accessories succeed in the electrical and mechanical property tests.

2. **Check the Accessories.**

List of supplied accessories:

- Test lead.
- Alligator clip (only for PD-351 and PD-352).
- K-type thermocouple.
- Multi-functional test socket.
- Soft bag.
- Quick reference guide.

You can check whether there is any loss of accessories with reference to this description. If it is found that there is any accessory lost or damaged, please get in touch with the distributor of PROMAX responsible for this service or the PROMAX local offices.

3. **Check the Complete Instrument.**


If it is found that there is damage to the appearance of the instrument, or the instrument can not work normally, or fails in the performance test, please get in touch with the PROMAX distributor responsible for this business or the PROMAX local offices. If there is

damage to the instrument caused by the transportation, please keep the package.

2.2 Install the Batteries

The multimeter is powered by two 1.5 V AA alkaline batteries (not included).



WARNING: To avoid false readings, which could lead to possible electric shock or personal injury, replace the battery as soon as the low battery indicator  appears.

Before replacing the battery, turn off the meter, disconnect test leads and any connectors from any circuit under test, remove test leads from the input terminals. Use only the specified battery type.

Use the following procedure to install the batteries.

- 1** Ensure that the rotary switch is at the **OFF** position. Remove test leads and any connectors from the input terminals.
- 2** Lift the tilt stand and loosen the screws with a suitable Phillips screwdriver and remove the battery cover.
- 3** Observe the battery polarity indicated inside the battery compartment, Insert the batteries.
- 4** Place the battery cover back in its original position and tighten the screws.



CAUTION: To avoid instruments being damaged from battery leakage, always remove the batteries and store them separately if the multimeter is not going to be used for a long period.

2.3 Adjusting the Tilt Stand

Pull the tilt-stand outward to its maximum reach (about 85 ° to the meter body).

2.4 Power On

- 1 To power ON the multimeter, turn the rotary switch to any other position except **OFF**.
- 2 To power OFF the multimeter, turn the rotary switch to the **OFF** position.

2.5 Sleep Mode



The multimeter automatically enters the sleep mode if the rotary switch is not moved or a key is not pressed for 15 minutes. (When the Bluetooth is activated, this function is disabled).

Pressing any key will turn the multimeter back to operation mode from the sleep mode.

One minute before auto power-off, the buzzer will sound "beep" five times to warn. Before it is shut off, the buzzer will sound a long "beep" then shut off.




NOTE: In sleep mode, the multimeter will still consume a little power. If the multimeter is not going to be used for a long period, the power should be turned off.

2.6 Backlight Control

- 1 To view the display in low-light conditions, you can activate the LCD backlight by pressing  for more than 2 seconds.
- 2 To turn off the backlight, press  for more than 2 seconds.

The backlight will last for 60 seconds.

2.7 Selecting the Range

- Auto ranging is set as default when the meter is powered on, **AUTO** is displayed.
- When auto ranging is enabled, press  to enter the manual range mode.
- In manual range, each additional press of  sets the multimeter to the next higher range, unless it is already in the highest range, at which point the range switches to the lowest range.
- When manual range is enabled, press  for more than 2 seconds to enter the auto ranging mode.

Note: Manual range is not available when measuring capacitance.

2.8 Description

► Front panel




Figure 1. Front Panel

▶ Rotary switch

- OFF** Power off.
- $\approx V$** DC or AC voltage measurement.
- $\approx mV$** DC or AC voltage measurement (up to 600 millivolts).
- $\bullet \rightarrow \Omega$** Continuity test, Capacitance measurement, Diode test, Resistance measurement.
- Hz%** Frequency measurement.
- hFE** Transistor measurement.
- TEMP** Temperature measurement.
- $\mu A \approx$** DC or AC current measurement (up to 600 microamperes).
- $mA \approx$** DC or AC current measurement (up to 600 milliamperes).
- $A \approx$** DC or AC current measurement.

▶ Keypad





Select

Select function:

- Select DC or AC
- Select °C or °F during temperature measurements
- Select Resistance / Diode / Continuity / Capacitance

Range

Auto/Manual range.

-  Select frequency/duty cycle.
-  Capturing Max. and Min. Values.
-  Backlight, Data Hold.
-  Relative Measurements, Bluetooth (PD-352).

► **Display screen**





Figure 2. Display screen.

-  Bluetooth enabled.
- AUTO** Auto range.
- MAX** Maximum reading.
- MIN** Minimum reading.



Data hold enabled.



Relative enabled.



Diode test selected.



Continuity test selected.



Battery is low.

DC

DC.

AC

AC.



Measurement display ("OL" is short for overload, indicates the reading exceeds the display range).


hFE °C °F

%RPM

Measuring units.

MkΩHz

μmVAnF



Analog bar graph.

▶ Measurement units

Sign	Description
M	Mega 1E+06 (1000000)
k	kilo 1E+03 (1000)
m	milli 1E-03 (0.001)
μ	micro 1E-06 (0.000001)
n	nano 1E-09 (0.000000001)

Sign	Description	Measurement type
°C	Degree Celsius	Temperature
°F	Degree Fahrenheit	
V	Voltage	Voltage
A	Ampere	Current
Ω	Ohm	Resistance
Hz	Hertz	Frequency
%	Percent,	Duty cycle
F	Farad	Capacitance
hFE	Current Amplification Factor	Transistor

► Input terminals

The terminal connections for the different measurement functions of the multimeter are described in the table below.



WARNING: Before starting any measurement, observe the rotary switch position of the multimeter, and then connect the test leads to the correct terminals.



CAUTION: To avoid damaging the multimeter, do not exceed the rated input limit.

Rotary switch position	Input terminals	Overload protection
$\approx V$	$V\Omega \rightarrow$ $\circ)) \leftarrow Hz\%$	COM 750 VAC/1000 VDC
$\approx mV$	$V\Omega \rightarrow$ $\circ)) \leftarrow Hz\%$	COM 250 VDC or Equivalent voltage RMS
$\circ)) \leftarrow$ $\rightarrow \Omega$	$V\Omega \rightarrow$ $\circ)) \leftarrow Hz\%$	COM 250 VAC or Equivalent voltage RMS
Hz%	$V\Omega \rightarrow$ $\circ)) \leftarrow Hz\%$	COM 250 VAC or Equivalent voltage RMS
TEMP	mATEMP μA hFE	COM 1 A / 250 V, fast-acting fuse
$\mu A \approx$	mATEMP μA hFE	COM
mA \approx	mATEMP μA hFE	COM
A \approx	20A	COM 20 A / 250 V, fast-acting fuse

3 Measurements

3.1 Measuring AC or DC Voltage



WARNING: Do not measure any voltage of over 1000 VDC or 750 VAC rms to avoid instrument damage or electric shock. Do not apply more than 1000 VDC or 750 VAC rms between the common terminal and the earth ground to avoid instrument damage or electric shock.

This multimeter displays DC voltage values as well as their polarity. Negative DC voltages will display a negative sign on the left of the display.

DC voltage ranges are 60.00 mV, 600.0 mV, 6.000 V, 60.00 V, 600.0 V, 1000 V.

AC voltage ranges are 60.00 mV, 600.0 mV, 6.000 V, 60.00 V, 600.0 V, 750 V.




- 1 Rotate the rotary switch to $\approx V$ or $\approx mV$. Default is DC measurement mode, **DC** will be displayed. Press Select to switch into AC measurement mode, **AC** will be displayed.
- 2 Connect the black test lead to the **COM** terminal and the red test lead to the $\overset{V\Omega}{\rightarrow} \leftarrow \text{Hz}\%$ terminal.
- 3 Probe the test points and read the display. Press Range to enable and cycle through the manual ranges.

3.2 Measuring Resistance



CAUTION: To avoid possible damage to your multimeter or to the equipment under test, disconnect the circuit power and discharge all high-voltage capacitors before measuring resistance.





Resistance ranges are 600.0 Ω , 6.000 k Ω , 60.00 k Ω , 600.0 k Ω , 6.000 M Ω , and 60.00 M Ω .

- 1 Rotate the rotary switch to  Ω .
- 2 Connect the black test lead to the **COM** terminal and the red test lead to the  terminal.
- 3 Probe the test points and read the display. Press  to enable and cycle through the manual ranges.

3.3 Testing Diodes



CAUTION: To avoid possible damage to your multimeter or to the equipment under test, disconnect the circuit power and discharge all high-voltage capacitors before testing diodes





- 1 Rotate the rotary switch to  Ω . Press  once to enter diode testing mode,  will be displayed.
- 2 Connect the black test lead to the **COM** terminal and the red test lead to the  terminal.

- 3 Connect the red test lead to the positive terminal (anode) of the diode and the black test lead to the negative terminal (cathode). The cathode of a diode is indicated with a band.
- 4 Read the diode forward bias. If the test lead connection is reversed, the multimeter will display "OL".

3.4 Testing for Continuity



CAUTION: To avoid possible damage to your multimeter or to the equipment under test, disconnect the circuit power and discharge all high-voltage capacitors before testing for continuity.

- 1 Rotate the rotary switch to . Press  twice to enter continuity testing mode,  will be displayed.
- 2 Connect the black test lead to the **COM** terminal and the red test lead to the  terminal.
- 3 Probe the test points to measure the resistance in the circuit. If the reading is below 30 Ω, the multimeter will beep continuously.



3.5 Measuring Capacitance



CAUTION: To avoid possible damage to the multimeter or to the equipment under test, disconnect circuit power and discharge all high-voltage capacitors before measuring capacitance. Use the DC voltage function to confirm that the capacitor is fully discharged.

Capacitance ranges are 40.00 nF, 400.0 nF, 4.000 uF, 40.00 uF, 400.0 uF, 4000 uF.

Note: For the 4000 uF range, the measuring duration should be over 30 seconds.

- 1 Rotate the rotary switch to . Press **Select** three times to enter capacitance measuring mode, the Farad units will be displayed.
- 2 Connect the black test lead to the **COM** terminal and the red test lead to the  terminal.
- 3 Probe the test points and read the display.

3.6 Measuring Frequency

Frequency ranges are 9.999 Hz, 99.99 Hz, 999.9 Hz, 9.999 kHz, 99.99 kHz, 999.9 kHz, and 9.999 MHz.

- 1 Rotate the rotary switch to **Hz%**.
- 2 Connect the black test lead to the **COM** terminal and the red test lead to the **VΩ→** terminal.
- 3 Probe the test points and read the display.
- 4 Press **Hz/Duty** to switch between the frequency and duty cycle measurements.

When measuring AC voltage or AC current, press **Hz/Duty** to cycle through frequency measuring, duty cycle measuring, and original measuring.

3.7 Measuring Transistor




WARNING: To avoid electrical shock or damage to the instrument, do not apply more than 250 VDC or 250 VAC rms between the **COM** terminal and the **mATEMP** terminal.

- 1 Rotate the rotary switch to **hFE**.
- 2 Connect the "+" plug of the multi-functional test socket to the **mATEMP** terminal and the "COM" plug to the **COM** terminal).
- 3 Determine whether the transistor is NPN or PNP type and locate the Emitter, Base and Collector leads. Insert leads of the transistor into the corresponding holes of the multi-functional test socket.

- 4 Read the hFE value.

3.8 Measuring Temperature

- 1 Rotate the rotary switch to **TEMP**.
- 2 Connect the **red connection** of the K-type thermocouple to the **mATEMP** terminal and the **black connection** to the **COM** terminal.
- 3 Probe the test points and read the display. Press  to change the temperature units between **°C** or **°F**.

3.9 Measuring DC or AC Current



WARNING: Never attempt an in-circuit current measurement where the open-circuit potential to earth is greater than 250 V. Doing so will cause damage to the multimeter and possible electric shock or personal injury.






CAUTION: To avoid possible damage to the multimeter or to the equipment under test, check the multimeter's fuse before measuring current. Use the proper terminals, function, and range for your measurement. Never place the test leads in parallel with any circuit or component when the leads are plugged into the current terminals.

Current ranges are 600.0 μ A, 6000 μ A, 60.00 mA, 600.0 mA, 6.000 A, and 20.00 A.

- 1 Turn off the power of the measured circuit. Discharge all high- voltage capacitors.
- 2 Connect the black test lead to the **COM** terminal. For currents below 600 mA, connect the red test lead to the **mATEMP** terminal; for currents within 600 mA – 20 A, connect the red test lead to the **20A** terminal.
- 3 Rotate the rotary switch to the appropriate position according to the measurement range, **μ A \approx** , **mA \approx** , or **A \approx** .
- 4 Disconnect the circuit path to be tested. Connect the black test lead to one side of the circuit (with a lower voltage); connect the red test lead to the other side (with a higher voltage). Reversing the leads will produce a negative reading, but will not damage the multimeter.
- 5 Select DC or AC measurement mode. Default is DC measurement mode, **DC** will be displayed. Press **Select** to switch into AC measurement mode, **AC** will be displayed.
- 6 Turn on the power of the measured circuit, and read the display. Press **Range** to enable and cycle through the manual ranges. If "OL" is displayed, it indicates the input exceeds the selected range and the rotary switch should be set to the position with higher range.
- 7 Turn off the power of the measured circuit and discharge all high-voltage capacitors. Remove the test leads and restore the circuit to the original condition.

4 Tools



4.1 Data Hold Mode

- 1 Press  to freeze the display during measurement,  will be shown on the display.
- 2 Press  again to exit this mode.

Note: This function is not available when measuring diodes and transistor.

4.2 Capturing Max. and Min. Values

In MAX mode, the measured maximum value will be held; In MIN mode, the measured minimum value will be held.



- 1 Press  to cycle between the MAX mode and MIN mode.
- 2 Press  for more than 2 seconds to exit the mode.

In this mode, the manual range mode will be activated automatically. Analog bar graph is not displayed. Auto power-off function is disabled.

Note: This function is not available when measuring diodes, capacitance, transistor, and frequency.

4.3 Making Relative Measurements

When making relative measurements, reading is the difference between a stored reference value and the input signal.

- 1 Press  to enter the relative mode. The measurement value when pressing  is stored as the reference value. In this mode, $REL \Delta$ (current reading) = input value - reference value.
- 2 Press it again to exit the mode. In relative measurement, the manual range mode will be activated automatically. (The relative measurement should be carried out under a certain range, that is, this function is only available under the manual range mode.) Analog bar graph is not displayed.

Note: This function is not available when measuring diodes, transistor, and frequency.

4.4 Buzzer Feature

- Press the function key, the buzzer will sound "Be..." in short.
- One minute before Auto Power-off the buzzer will sound "beep" five times to warn. Before it is shut off, the buzzer will sound a long " beep" then shut off.
- The buzzer will sound "beep..." continuously to warn when the measured DC voltage is higher than 1000 V, AC voltage is higher than 750 V, or the measured DC/AC mV mode is higher than 600.0 mV.

- The buzzer will sound long when the short circuit resistance is less than about 30W during the continuity test.
- When the Bluetooth function is time out, the buzzer will sound “beep” two times.

5 Bluetooth Function (PD-351 and PD-352)

PD-351 and **PD-352** multimeter supports communications with Android based smart device through Bluetooth. You can use the free application software on the Android based smart devices to monitor the measurements, perform remote control, view trending graphs, etc. The recorded data can be saved as CSV file. More than one meters can be connect simultaneously.

Note: Bluetooth connectivity works over a range of about 10 meters. The work range is much longer in open-sided and non-occluded wide range environment, even up to 20 meters. If the Bluetooth function in the multimeter is idle for 10 minutes, the Bluetooth will be turned off automatically. Before turning off, the buzzer will sound "beep" two times.

5.1 System Requirements of Mobile Devices

- Android devices with Bluetooth connectivity 4.0.
- Android Versions: 4.4 and above.

5.2 Install the application software

Install the free PROMAX application software (Multimeter.apk). It can be downloaded from here:




- Scan QR Codes below with your Android based smart device to install the app.



- Visit www.promax.es/smartphone-apps/pd-35x to download APK file and install into the device.

Note: To allow the installation of this android application from a place other than the official website of Google "Play", on your mobile device go to "Settings" / "Security" and enable the "Unknown sources" option.

5.3 How to Connect

- 1 Turn on the multimeter, press and hold  until  appear on the display.
- 2 Launch the application .
- 3 Click the icon on the top left of the screen to launch device connection.




Figure 3.

- 4 If the Bluetooth function is activated, skip this step; if not, a dialog box (similar to figure below) will ask whether to turn on Bluetooth. Click "Yes".



Figure 4.

- 5 Now, the blueetooth will try to detect the multimeter. Click to scan to scan again.




Figure 5.

- 6 In the list of devices should appear PD-351 or PD-352. Select the right one to pair. After pairing a confirmation message should appear on screen.




Figure 6.

- 7 You can repeat this procedure to connect the mobile device to a second multimeter, by clicking on "No device" on the top right of the screen and following the steps described above.

5.4 User Interface




Figure 7.




Figure 8.

► Function Description Table

Display	Function
DC	Direct Current
AC	Alternating Current
RES	Measuring Resistance
DIO	Testing Diodes
BEEP	Testing for Continuity

Display	Function
CAP	Measuring Capacitance
Hz	Measuring Frequency
DUT	Measuring Duty Cycle
hFE	Measuring Transistor
TEMP	Measuring Temperature

6 Operations

■ **Customize the meter name**

The device name of meter can be customized. Press and hold the name on the top left of the screen, a dialog box below will pop up. You can input the customized name, this name will be memorized in the device. If this meter is connected to the same device next time, the customized name will be shown. If this meter is connected to another device, the name is still the default one or the customized name to the connected device.










Figure 9.

- **Add meter:** In double view, click  softkey.
- **Select meter:** In single or double view, click  or  softkey.
- **Disconnect meter:** In single or double view, click  or the meter name.
- **Remote Control:** In single view, the control softkeys (blue background softkeys, as Hold, Rel, Select, etc.) can be short or long pressed to perform control, just as press the corresponding keys of multimeter.

■ Voice out function

Provide an audible out of the readings through the text-to-speech (TTS) engine on your Android device. Click the  icon on the top right of the screen to turn on voice out. Click  to turn off. In settings menu on your Android device, you can set the language-specific voice for the spoken text, or speech rate etc.

You may change to different voices by installing different TTS engines.


- **About:** Click , and click "About", the following interface is shown.



Figure 10.

- **Data Graph and Table:** Click to view data graph and table. Click to show setting menu.

Data Graph & Table




Figure 11.

► **Setting menu**

Softkey	Description
Open local file	Read the saved file (.CSV)
Save data	Save the displayed data into .CSV file
Share	Share the measurements via the installed sharing apps
Clear data	Clear the data displayed
Setting	<p>Sampling Interval: Set the sampling interval in the application software.</p> <p>Enable Period: Log data within the defined period.</p> <p>Record Period: Define the period time if the period is enabled.</p> <p>Fill: Check to fill the area as blue below the data line.</p>
Exit	Exit the APP

Note: In trending graph, you can pinch the screen to zoom. The Y axis (value) can be zoomed by gesturing along the up-down direction, and the X axis (time) can be zoomed by gesturing along the left-right direction.

7 Technical Specifications

All these specifications apply to the multimeter unless otherwise explanation.

Standard conditions: The environment temperature is 18 °C to 28 °C, the relative humidity is less than 80%.

Function		Measurement Range	Resolution	Accuracy
DC Voltage (V)	mV	60.00 mV / 600.0 mV	0.01 mV	±(0.8%+2dig)
	V	60.00 mV / 600.0 mV / 6.000 V / 60.00 V	0.1 mV	
		600.0 V / 1000 V	0.1 V	
AC Voltage (V)	mV	60.00 mV / 600.0 mV	0.01 mV	±(0.8%+2dig)
	V	60.00 mV / 600.0 mV / 6.000 V / 60.00 V	1 mV	±(0.8%+2dig)
		600.0 V / 750 V	0.1 V	±(1%+3dig)
DC Current (A)	μA	600.0 μA	0.1 μA	±(0.8%+2dig)
	mA	600.0 μA / 6.000 mA / 60.00 mA / 600.0 mA / 6.000A	0.01 mA	±(0.8%+2dig)
	A	20.00 A ¹	1 mA	±(1.2%+3dig)
AC Current (A)	μA	600.0 μA	0.1 μA	±(1%+3dig)
	mA	600.0 μA / 6.000 mA / 60.00 mA / 600.0 mA / 6.000 A	0.01 mA	±(0.8%+2dig)
	A	20.00 A ¹	1 mA	±(2%+3dig)
Resistance (Ω)		600.0 Ω / 6.000 kΩ / 60.00 kΩ / 600.0 kΩ / 6.000 MΩ / 10.0 0 MΩ	0.1 Ω	±(0.8%+2dig)
		60.00 MΩ	0.01 MΩ	±(2%+3dig)

¹ When measuring current, for 10 A to 15 A, the measuring duration should not be over 2 minutes within 10 minutes, and in this 10 minutes, no other current should flow through except within the measuring duration; for 15 A to 20 A, the measuring duration should not be over 10 seconds within 15 minutes, and in this 15 minutes, no other current should flow through except within the measuring duration.


Function	Measurement Range	Resolution	Accuracy
Capacitance (F)	40.00 nF	0.01 nF	±(2.5 %+3dig)
	400,0 nF / 4,000 µF/ 40,00 µF	0.1 nF	±(2.5 %+3dig)
	400.0 µF / 4000 µF ²	0.1 µF	±(3 %+5dig)
Frequency³ (Hz)	9,999 Hz / 99,99 Hz / 999,9 Hz / 9,999 kHz / 99,99 kHz / 999,9 kHz / 9,999 MHz	1 mHz	±(0.8 %+2dig)
Duty Cycle⁴ (%)	0,1% - 99,9% (Typical: Vrms= 1 V, f=1 kHz)	0.1 %	±(1.2 %+3dig)
	0,1% - 99,9% (≥1 kHz)		±(2.5 %+3dig)
Temperature (°C/°F)	-50 °C to 400 °C	1 °C	±(2.5 %+3dig)
	-58 °F to 752 °F	1 °F	±(4.5 %+5dig)

² When measuring capacitance, for the 4000 µF range, the measuring duration should be over 30 seconds.

³ When measuring frequency, the typical waveform is Square or Sine. The signal meets the following conditions.

Frequency	Amplitude (rms)
1 Hz – 4 MHz	100 mV
4 MHz – 8 MHz	≥200 mV
8 MHz – 10 MHz	≥300 mV

⁴ When measuring duty cycle, the typical waveform is Square.

Display	6000	
Frequency Response (Hz)	PD-351	(40 - 400) Hz
	PD-352; PD-350	(40 - 10k) Hz
Sample rate for digital data	3 times/second	
Sample rate for analog bar graph	30 times/second	
Bluetooth	PD-351; PD-352	√
	PD-350	Without
Auto ranging	√	
True RMS	PD-352; PD-350	
Diodes Test	√	
Measuring Transistor	√	
Sleep Mode	√	
Continuity Test	√	
Low battery indication	√(The "  " is displayed when the battery is under the proper operation range.)	
Data Hold	√	
Relative Measurement	√	
MAX/MIN Value	√	
LCD Backlight	√	
Analog bar graph	61 Segments	
Input Protection	√	
Input Impedance	10 MΩ	

Battery	3 V (1.5 V × 2) AA alkaline batteries (not included)
LCD Size	69 mm * 52 mm
Weight (without package)	0.32 kg
Dimension	85 mm * 185 mm * 30 mm
Working temperature	0 °C to 40 °C
Storage temperature	-10C o 60 °
Relative Humidity	≤ 80%
Altitude	Operating: 3,000 m Non-operating: 15,000 m

Note: Equipment specifications are set in these environmental operating conditions. Operation outside these specifications are also possible. Please check with us if you have specific requirements.

RECOMMENDATIONS ABOUT THE PACKING

It is recommended to keep all the packing material in order to return the equipment, if necessary, to the Technical Service.


8 Maintenance

8.1 **Cleaning the multimeter**

Wipe the case occasionally with a damp cloth. **DO NOT** use chemicals, cleaning solvents, abrasives or detergents.

8.2 **Replacing the battery**

This meter is powered by a 6F22/LR22 or equivalent 9-volt battery.

When the multimeter displays the "" the battery must be replaced to maintain proper operation. Use the following procedure to replacing the battery:

1. Unscrew and remove the rear panel with the aid of a suitable Phillips screwdriver.
2. Remove the battery and replace it by a new one of 9 V 6F22/LR22 type.
3. Back to placing the rear panel and screw it again.

8.3 Fuse replacement

WARNING: Disconnect all the test leads before initiating the fuse replacement process. Power off the instrument.

Fuses are located inside the instrument. In order to replace them you must follow these instructions:

1. Unscrew and remove the rear panel
2. Remove old fuse and replace it by a new one.

Fuses must be:

1 A F250V

**USING DIFFERENT TYPE OF FUSES COULD
DAMAGE THE INSTRUMENT.**

3. Back to placing the rear panel and screw it.