

FCC Channels and frequencies table

| | | | | | | | | | |
|------------|------------|-----------|------------|-----------|------------|-----------|------------|-----------|------------|
| A02 | 55,25 MHz | 17 | 489,25 MHz | 32 | 579,25 MHz | 47 | 669,25 MHz | 62 | 759,25 MHz |
| A03 | 61,25 MHz | 18 | 495,25 MHz | 33 | 585,25 MHz | 48 | 675,25 MHz | 63 | 765,25 MHz |
| A04 | 67,25 MHz | 19 | 501,25 MHz | 34 | 591,25 MHz | 49 | 681,25 MHz | 64 | 771,25 MHz |
| A05 | 77,25 MHz | 20 | 507,25 MHz | 35 | 597,25 MHz | 50 | 687,25 MHz | 65 | 777,25 MHz |
| A06 | 83,25 MHz | 21 | 513,25 MHz | 36 | 603,25 MHz | 51 | 693,25 MHz | 66 | 783,25 MHz |
| A07 | 175,25 MHz | 22 | 519,25 MHz | 37 | 609,25 MHz | 52 | 699,25 MHz | 67 | 789,25 MHz |
| A08 | 181,25 MHz | 23 | 525,25 MHz | 38 | 615,25 MHz | 53 | 705,25 MHz | 68 | 795,25 MHz |
| A09 | 187,25 MHz | 24 | 531,25 MHz | 39 | 621,25 MHz | 54 | 711,25 MHz | 69 | 801,25 MHz |
| A10 | 193,25 MHz | 25 | 537,25 MHz | 40 | 627,25 MHz | 55 | 717,25 MHz | 70 | 807,25 MHz |
| A11 | 199,25 MHz | 26 | 543,25 MHz | 41 | 633,25 MHz | 56 | 723,25 MHz | 71 | 813,25 MHz |
| A12 | 205,25 MHz | 27 | 549,25 MHz | 42 | 639,25 MHz | 57 | 729,25 MHz | 72 | 819,25 MHz |
| A13 | 211,25 MHz | 28 | 555,25 MHz | 43 | 645,25 MHz | 58 | 735,25 MHz | 73 | 825,25 MHz |
| 14 | 471,25 MHz | 29 | 561,25 MHz | 44 | 651,25 MHz | 59 | 741,25 MHz | 74 | 831,25 MHz |
| 15 | 477,25 MHz | 30 | 567,25 MHz | 45 | 657,25 MHz | 60 | 747,25 MHz | 75 | 837,25 MHz |
| 16 | 483,25 MHz | 31 | 573,25 MHz | 46 | 663,25 MHz | 61 | 753,25 MHz | 76 | 843,25 MHz |
| | | | | | | | | 77 | 849,25 MHz |
| | | | | | | | | 78 | 855,25 MHz |