


HOME SCREEN



HOW TO WORK WITH THE CUSTOMIZABLE ADJUSTABLE PANELS



- 1** Change the tool displayed on this panel.
- 2** Maximize the panel.
- 3** Configure the options of the panel tool.
- 4** Maximize the panel to full screen (+) or restore (-) its original position.

INFORMATION BAR

Touch to access **settings**.


Signal information and settings access.

Unlocked

Locked

Return to the main screen.


SIGNAL INPUTS AND OUTPUTS



- 1** **ON/OFF.** Hold down for a second to connect or disconnect.
- 2** **USB 3.0 port** for WiFi dongles, GPS receivers or to increase the memory of the device with USB sticks.
- 3** **Rj45 connection** for analysis of IP television signal.
- 4** Reserved **SFP+ port** for specialized Small Form-Factor Pluggable interfaces.
- 5** **ASI / SDI** signal output.
- 6** **ASI / SDI** signal input.
- 7** **1 PPS** or **10 MHz** reference synchronization signal input.
- 8** Slot for **CAM** modules.


DATA INTERFACE: SIDE PANEL

- 1** Output with **HDMI™** technology (supports HDMI 1.4 b with 2.9 Gb/s and up to 3840 x 2160 @ 30 Hz).
- 2** **USB Host / Device connection** (selectable).
- 3** **RJ45 connection** for remote control.
- 4** Analog **Video/Audio** Input and Output.
- 5** Connection for **external DC charger**.
- 6** **LED battery status indicator**.
 - Charging.
 - Charging complete.
 - Battery not detected (blinking).
 - Battery is low (shutting down).





Note: Some of the connections or functions described in this quick guide may not be available in all versions of the test instrument.

MOST COMMON TOUCH GESTURES



① **Access the Top Menu:** Swipe from the top edge of the screen.

② **Access to settings** menu: swipe right from the left edge of the screen.



ON-SCREEN ICON REFERENCE

SIGNAL QUALITY BASED ON THRESHOLDS

- ✓ **Correct Quality** (According to User-Defined Thresholds).
- ⚠ **Quality at the limit** of Acceptable Value.
- ✗ **Unacceptable** Quality (According to User-Defined Threshold).

SMART BATTERY

- 🔋 **Battery in use.** The stimated remaining life is displayed.
- 🔌 **Charging battery.** The device is connected to the power source.
- 🔌 **Battery depleted.** Minimum battery level; the device will shut down shortly.


Note: Some of the connections or functions described in this quick guide may not be available in all versions of the test instrument.

HOME MENU



TOP MENU*

Workspace, task planner,
I/O settings (USB,
GPS, HDMI)



Audio and
Brightness
Options.

Notification
Area.

* Available options may vary depending on operating mode.

