


## FRONT VIEW




- 1 ON / OFF**  
It turns ON or OFF the instrument.
- 2 CONFIGURATION**  
It access or exits the configuration menu.
- 3 F Connector** to connect F-F adapter (F-BNC or F-IEC), for output signals that have been activated.
- 4 Mini-USB** connector for data transferring and to control the instrument via PC.
- 5 DISPLAY**  
It is the display with backlight.
- 6 DC power adapter** input.
- 7 CURSOR**  
It allows you to change the configuration options and the signal parameters.
- 8 SELECTION**  
It allows you to scroll down the configuration options and move between the active fields than define the signal parameters.



## FUNCTION GENERATOR


It sets the characteristics of the signals generated by the instrument. It can enable or disable the signal in order to check the transmission channel.



- ① Power level of pilot signal.
- ② Frequency of pilot signal.
- ③ Pilot signal selected.
- ④ Edit parameters blocked.
- ⑤ Mains power.
- ⑥ Battery level.
- ⑦ Selected pilot signal enabled ☒ / disabled ■.
- ⑧ Pilot signals enabled / disabled (dotted line).
- ⑨ Band of frequencies for pilot signals.

## FUNCTION CONFIGURATION

It sets several parameters of the instrument.



- Language:** Spanish / English / French / German.
- Beep:** on / off.
- Backlight mode:** on / off / auto.
- Units:** dBmV / dBµV / dBm.
- LCD contrast:** - / +.
- Lock pilots:** on / off.
- Presets:** Mem 01 - 08 (sets of pilot signals on memory).